



- NOTES:
- UNLESS OTHERWISE SPECIFIED, ALL RESISTORS IN OHMS, ±5%, 1/2 W. ALL CAPACITORS IN MFD AT 100V.
 - ⊖ INDICATES SCREWDRIVER ADJUSTMENT.
 - ⚠ ADJUST TR-1 (BIAS POT) AT 120V LINE, 4 OHM LOAD, 5MV ACROSS R24 AND R49.
 - ⚠ ADJUST TR-2 (REVERB SENSITIVITY) FOR MAXIMUM REVERB WITHOUT FEEDBACK.
 - ⚠ ADJUST TR-3 (TREMOLO SENSITIVITY) UNTIL TREMOLO JUST STOPS WITH INTENSITY CONTROL OFF.

COMPONENT BASING

